

# ナカタ<sup>®</sup> 温度・湿度計

コード：NJ-2099 TH

## 取扱説明書

### 仕様



1. 測定範囲  
温度：0℃～50℃（32°F～122°F）  
湿度：20%～99%（RH）
2. 精度  
温度：±1℃（±1.8°F）（0℃～50℃で）  
湿度：  
±3%（0℃～50℃の温度、40%～80%の湿度で）  
±5%（20%-40%, 80%-99%の湿度で）
3. 最小表示量  
温度：0.1℃（0.1°F）  
湿度：1%
4. 電池：1.5VAAA（7#）

### 用要領

1. 電池が付いているか確認して下さい。付いていない場合、電池を入れてください。
2. 電池を入れた後、温度・湿度を画面に表示されます。（温度は上、湿度は下）。
3. 温度・湿度の最大値・最小値のメモリ：  
＜1＞ コントロールパネルの MAX/MIN スイッチを押すと、『CLEAR』を最終に押した最大値を表示されます。  
＜2＞ コントロールパネルの MAX/MIN スイッチをもう一度押すと、『CLEAR』を最終に押した最小値を表示されます。  
＜3＞ コントロールパネルの MAX/MIN スイッチをもう一度押すと、現在の測定値を表示されます。
4. MAX/MIN 数値を消すには  
最大値（MAX）・最小値（MIN）が表示される時にコントロールパネルの『CLEAR』スイッチを押します。
5. 温度目盛切換  
コントロールパネルの C/F スイッチを押すと、℃と°F 切換することができます。



### 置き方

1. 温度・湿度計の背面に穴がありますので壁にかけることができます。
2. スタンドがありますので机に置くこともできます。

### 使用上の注意

電池の電圧が低下している場合は画面に “  ” 表示が表示されます。直ちに電池交換を行ってください。

# NAKATA<sup>®</sup> THERMO-HYGROMETER

Model: NJ-2099 TH

## USER INSTRUCTION



### Feature

1. Measurement Ranges:  
Temperature: : °C ~ 50 °C (32 °F ~ 122 °F)  
Humidity: 20% ~ 99% (RH)
5. Accuracy:  
Temp.: ± 1 °C (± 1.8 °F) (0 °C ~ 50 °C で)  
Humidity:  
± 3% (0 °C ~ 50 °C & 40% ~ 80% RH)  
± 5% (20% - 40%, 80% - 99% RH)
6. Resolution:  
Temp.: 0.1 °C (0.1 °F)  
Humidity: 1%
7. Battery: 1.5VAAA (7 #)

### Usage


1. Open the battery cover and remove the battery insulator as the direction indicated on unit back, then strip the protection film on the unit face, the hygro/thermometer is prepared for use now.
2. On switching on, the display shows the current temperature above and humidity below.
3. Memory for MAX/MIN humidity/temperature:  
< 1 > Press MAX/MIN key, the max. value after the last "CLEAR" is displayed  
< 2 > Press MAX/MIN key again, the min. value after the last "CLEAR" is displayed.  
< 3 > Press MAX/MIN key once more, then returns to current Temperature/Humidity display.
4. Clear the MAX/MIN value:  
When the max or min value of temperature and humidity is displayed, press CLEAR key to clear the memory of MAX/MIN value.
5. Changing temperature measurement scale  
By pressing C/F key to switch C/F temperature unit



### Installation

1. The meter can be hung against the wall
2. The meter can stand on the table.

### Notice

When the symbol “  “ occurs on LCD display, the battery need to be replaced to assure accuracy.